



## Analog Converter Unit (ACU) FAQs

<b>What cameras may be used with the ACU?</b>	Any analog camera will be converted to digital and can then be viewed though Total Connect™ Video Services.
<b>How many cameras may be used per ACU?</b>	The limit is one camera per ACU.
<b>How many ACUs may be used per Total Connect Video account?</b>	Six ACUs per account may be used.
<b>Will video analytics work with the ACU and other cameras?</b>	Yes. The ACU is capable of full analytics excluding the pan and tilt feature.
<b>How is the ACU configured?</b>	The ACU is configured the same way as our IP CAMs. You will enter the MAC number from the device on to your AlarmNet account through AlarmNet Direct.
<b>How does the ACU connect to the AlarmNet network?</b>	Using a Wi-Fi encrypted service via WPS (Wi-Fi Protected Setup) through AlarmNet.
<b>Is the ACU wired or wireless?</b>	The ACU is hardwired for power but has WPS button capability for Wi-Fi connection to a WAP or router.